

## How to raise the mast on a Rhodes 22 using the mast hoist system

0 Set up	
0.1 Install the transom mast carrier	
1 Disengage the mast and tie downs	
1.1 Undo all traveling tie downs except that bundling the mast, boom, genoa.	
1.2 Disengage the mast from the bow pulpit and move the bundle aft	
2 Position the mast	
2.1 Line up the 3/8" cross hole near mast bottom with slot in mast step.	
2.2 Install the 3/8"x4" mast pivot bolt and wing nut. Don't tighten to allow mast to rotate.	
3 Set up the crane	
3.1 Winch out the crane brake	
3.2 Make fast to deck cleat	
3.3 Make fast to bail on mast	
4 Connect stays, shrouds	
4.1 Connect back stays to chain plates	
4.2 Tape back stays to stern rail to keep slack in cockpit	
4.3 Connect two forward lower shrouds to cabin top chain plates with chain extenders.	
4.4 Conect two upper shrouds to their chain plates with turnbuckles open.	
5 Raise the mast	
5.1 Turn the brake winch handle	
5.2 Don't override any complaints.	
6 Secure the mast	
6.1 Disconnect the chains and attach forward lower turnbuckles to chain plates.	
6.2 Conect all lower shrouds.	
6.3 Conect the jib.	
6.4 Remove the crane.	
7 Final	
7.1 stow the crane and transom mast carrier	
7.2 Connect the pop top slider to the hatch	